

Palm Springs Rattan[®]

GARDEN CLASSICS[®]

--- CARE & MAINTENANCE ---

Hampton Loomed Wicker and Fabric

Hampton Collection is best for limited exposure outdoor use.

Supplies Needed

1. Bucket or Spray bottle
2. Soft Bristle Brush or Sponge
3. Eye protection

Cleaning & Maintaining Loomed Wicker

Always wear eye protection to prevent foreign liquid or material from entering the eye.

It is best to remove soiling and spills as they happen as they will be much easier to clean. This can be done by rinsing the product thoroughly with fresh water and brushing with a **soft** bristle brush if necessary.

To remove stubborn dirt or stains from the frame or heavy soiling that has accumulated over time clean the frames with warm, soapy water and mild soap. Brush with a soft bristle brush as necessary.

**DO NOT USE A PRESSURE WASHER TO CLEAN YOUR FURNITURE.
IT WILL VOID YOUR MANUFACTURERS WARRANTY.**

The force of the compressed water can damage or remove the finish and could harm the fabric.

Cleaning & Maintaining the Cushions and Fabric

Always wear eye protection to prevent foreign liquid or material from entering the eye.

Cushions

After a soaking rain or anytime the cores of the cushions get wet it is best to stand the cushion on end to allow them to drain more quickly. This will prevent mold and mildew growth between the frame and the cushion.

Spot wash the fabric to clean spills by using a sponge or a soft bristle brush with a warm soapy solution of mild detergent (Joy or Ivory liquid). Brush or sponge the soiled area and rinse thoroughly with fresh water. Allow to air dry. Repeat if necessary.

DO NOT MACHINE WASH OR MACHINE DRY THE CUSHION CASINGS. YOU COULD DAMAGE THE SEAMS OF THE CASE.